



### Touring 150 DE Diagram 1 ---- Frame

# on this page	Name/Description	Category	Phone Reference #
1	Gas Cap	<a href="#">Fuel, Air &amp; Exhaust</a>	150T-H-1-1
2	Fuel/Gas Tank	<a href="#">Fuel, Air &amp; Exhaust</a>	150T-H-1-2
3	10mm Lock Nut	<a href="#">Body &amp; Hardware</a>	150T-H-1-3
4	Fuel Sensor/Float	<a href="#">Fuel, Air &amp; Exhaust</a>	150T-H-1-4
5	Fuel Sensor O-ring	<a href="#">Fuel, Air &amp; Exhaust</a>	150T-H-1-5
6	Fuel Sensor Retainer	<a href="#">Fuel, Air &amp; Exhaust</a>	150T-H-1-6
7	8mm Bolts ~ 30mm	<a href="#">Body &amp; Hardware</a>	150T-H-1-7
8	Floor Board Support RT	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-8
9	Battery Box Support	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-9
10	Floor Board Support FRT	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-10
11	Handlebar Stem	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-11
12	8mm Bolts ~60mm	<a href="#">Body &amp; Hardware</a>	150T-H-1-12
13	Frame	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-13
14	Upper Shock bolt	<a href="#">Body &amp; Hardware</a>	150T-H-1-14
15	Right Rear Shock	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-15
16	Lower Shock bolt	<a href="#">Body &amp; Hardware</a>	150T-H-1-16
17	Left Rear Shock	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-17
18	Rear Support	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-18
19	Floor Board Support FLT	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-19
20	Side Stand Springs	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-20
21	Side stand	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-21
22	Side Stand Bolt(10mm)	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-22
23	Floor Board Support LT	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-23
24	10mm Bolts ~30mm	<a href="#">Body &amp; Hardware</a>	150T-H-1-24
25	10mm Washer	<a href="#">Body &amp; Hardware</a>	150T-H-1-25
26	Center/Service Stand	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-26
27	Center Stand Roller Bolt	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-27
28	Center Stand Roller	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-28
29	Front Seat Latch	<a href="#">Body &amp; Hardware</a>	150T-H-1-29
30	Seat Latch Short Cable	<a href="#">Body &amp; Hardware</a>	150T-H-1-30
31	8mm Bolt ~20-25mm	<a href="#">Body &amp; Hardware</a>	150T-H-1-31
32	Seat Latch Long Cable	<a href="#">Body &amp; Hardware</a>	150T-H-1-32
33	Seat Latch Plate	<a href="#">Frame, Steering &amp; Susp</a>	150T-H-1-33
35	Rear Seat Latch	<a href="#">Body &amp; Hardware</a>	150T-H-1-35
37	6mm Bolts ~ 12	<a href="#">Body &amp; Hardware</a>	150T-H-1-37